## Work Order ID 52631

October 5, 2009 10:05:57 AM

Item ID:

D3140-89

Doubler

QC:

**Revision ID:** 

Item Name:

Required Date: 10/09/09

**Start Date:** 

10/05/09

Start Qty: 2.00

Req'd Qty: 2.00



Accept



Setup Start





**Cust Item ID:** 

**Customer:** 

Reference:

**Approvals:** 

Process Plan:

Date:

Date: 09 /10/0 STooling:

SPC (Y/N):

Date:

Date:

Run

Start Stop



Sequence ID/ Operation Set Up/ Draw Plan Reject Draw Accept Reject Insp. Work Center ID Description Run Hours Number Rev. Code Qty Qty Number Stamp **Draw Nbr Revision Nbr** 

D3140

Rev F

100

Waterjet FLOW CNC Waterjet FLOW WATER JET

Memo

1-Cut as per Dwg D3140 Dwg Rev:\_\_\_\_\_

Prog Rev: 2-Deburr if necessary 0.00

0.00

B910-5

QC2- Inspect parts off machine FAI/FAIB

Memo

0.00

QC

0.00

1B910-15

Quality Control

120

110

QC8- Inspect parts - second check

Memo

0.00

Quality Control

# **Dart Aerospace Ltd**

W/O:			W	ORK ORDER CHAN	GES		· · · · · · · · · · · · · · · · · · ·	<del></del>		
DATE	STEP	PRO	PROCEDURE CHANGE			Ву	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector
										7
			-							
Part No	:	PAR #:	Fault Cate	egory:	NCR	: Yes I	10 <b>DQ</b>	A:	_ Date: _	
Resolution:			Disposition: Q			QA: N/C Closed: Date:				
NCR:			WORK ORD	ER NON-CONFORM	IANCE	(NCR)	)			
DATE	STEP	Description of NC	NC Corrective Action			Section B Verific			Approval	Approval
DAIL	SIEF	Section A	Initial Chief Eng	Action Description Chief Eng	1	Sign & Date	Secti		Chief Eng	QC Inspector
										:
			·							

.NOTE: Date & initial all entries

#### Work Order ID 52631

October 5, 2009 10:05:57 AM

Item ID:

D3140-89

F **Revision ID:** 

Item Name: Doubler

10/05/09 **Start Date:** Required Date: 10/09/09

Start Qty: 2.00

Req'd Qty: 2.00



Accept

Setup Start

Stop



Page 2

**Cust Item ID:** 

**Customer:** 

Reference:

Approvals:

Process Plan:

Date:

Tooling:

SPC (Y/N):

Date: Date: Run

Start Stop

Sequence ID/

**Work Center ID** 

Small Fab

Small Fab

Operation Description

Small Fab

Set Up/

**Run Hours** 0.00

Draw Number

Draw Rev.

Plan Code

Accept Qty

Reject Reject Qty

Insp. Number Stamp

0.00 Memo

1-Scuff surfaces with 80grit sandpaper per QSI 006

Date: \_\_\_\_

2-Deburr. No sharp edges

140

QC

QC5- Inspect part completeness to step on W/O

Memo

0.00

Quality Control

150

HandFinish

Hand Finishing

Chemical Conversion Coat per QSI005 4.1

0.00

mp 09/16/06

Memo

<b>Dart Aerospace</b>
-----------------------

W/O:	•		WC	RK ORDER CHANG	ES					
DATE	STEP	PR	OCEDURE CHAI		Ву	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector	
			1							
Part No		PAR #:	Fault Cate	gory:	NCR: Yes	No DQ	A:	_ Date: _		
	Resolution: Disposition:				QA: N/C Closed: Date:					
NCR:			WORK ORDI	R NON-CONFORMA	NCE (NC	R)				
DATE	STEP Description of NC		Corrective Action Section B			Veriticati		Approval	Approval	
	0.2.	Section A	Initial Chief Eng	Action Description Chief Eng	Sign Date	& Secti		Chief Eng	QC Inspector	

. NOTE: Date & initial all entries

F

October 5, 2009 10:05:57 AM

Page 3

Item ID:

D3140-89

Accept

Setup Start

Stop



**Revision ID:** 

Item Name: Doubler

Required Date: 10/09/09

10/05/09

Start Qty: 2.00

Req'd Qty: 2.00



**Cust Item ID:** 

**Customer:** 

Reference:

**Start Date:** 

Approvals:

**Process Plan:** 

Date:

**Tooling:** 

Date:

Run

Start

QC:

Date:

SPC (Y/N):

Date: \_\_\_\_\_

Stop

Sequence ID/ **Work Center ID** 

160



Quality Control

**Operation** Description

QC3-Inspect Part Finish

Memo

Set Up/ **Run Hours** 

Draw Number Draw Rev.

Plan

Accept Qty Code

Reject Qty

Insp. Reject Number

Stamp

170

Packaging

Packaging

Identify as per dwg & Stock Location: 6 A

Memo

0.00

209/10/04

180

QC

Quality Control

QC21- Final Inspection - Work Order Release

0.00

09/10/06 Ad MF 10-06

Memo

0.00

W/O:			WC	ES						
DATE	STEP	PRO	OCEDURE CHANGE			Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector	
······································										
			***************************************							
Part No	:	PAR #:	Fault Cate	gory:	NCR: Yes	No <b>DQ</b>	<b>A</b> :	Date: _		
	Resolution: Disposition:				QA: N/C Closed: Date:					
NCR:			WORK ORD	ER NON-CONFORMA	NCE (NCI	7)				
DATE	STEP Description of NC			on B	Verifi	cation	Approval	Approval		
DAIL	SILF	Section A	Initial Chief Eng	Action Description Chief Eng	Sign Date	& Sect	tion C	Chief Eng	QC Inspector	
									į	
				*						

. NOTE: Date & initial all entries

## **Picklist Print**

October 5, 2009 10:05:56 AM

Work Order ID: 52631

Parent Item:

D3140-89RevF

Parent Item Name: Doubler

Comments:



**Start Date:** 10/05/09

Start Qty: 2.00

Required Date: 10/09/09

Required Qty: 2.00

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Remaining Qty To Pick	Qty Issued	Date Issued	Status
M2024T3S.032		Purchased	No		••	100	sf	78.4179	3.4947			
											189-10	) <del>-4</del>

2024-T3 .032 sheet

Warehouse	Loc Oty	Loc Code	
<u>Location</u>			
Main Warehouse			
MAT	78.41793158		
102942	1.5		
105555	4.0684		
106272	5.3		
108595	1.2		
109240	7.02		
110778	21.9106316		
111699	34,4189		111699
18147	3		

Dart Aerospa	ce	Ltd
--------------	----	-----

	-									
W/O:			W	ORK ORDER CHANG	GES					
DATE	STEP	PR	OCEDURE CHANGE			Ву	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector
					•		,			
							,			ļ
		_							]	
Part No	•	PAR #:	Fault Cate	egory:	_ NC	R: Yes I	No DQA	•	Date: _	
Resolution:				_ Disposition: QA: N/C Closed: Date:						
NCR:			WORK ORD	ER NON-CONFORM	ANCE	(NCR	)			
DATE	STEP	Description of NC	Corrective Action Section B			Verit		cation Ap	Approval	Approval
DAIL	SILF	Section A	Initial Chief Eng	Action Description Chief Eng		Sign & Date	Sectio		Chief Eng	QC Inspector
										į
								- 13 tax ann		
				delife selection and the selec					1	
		·								-

NOTE: Date & initial all entries

<sup>,</sup> H:\fFORMS\Quality Assurance\approved QA\NCRWO RevE

DART AEROSPACE LTD	Work Order: Sacal	
	Part Number: D3140~49	
Description: Doublet		
Inspection Dwg: DZ14D-89 Rev: F	Page 1 of 1	·

# FIRST ARTICLE INSPECTION CHECKLIST

X First Article Prototype

Drawing	Tolerance	Actual	Accept	Reject	Method of Inspection	Comments
Dimension	<u> </u>	Dimension	16			
3.65	4030	3.048	*	,		
26.55	4- 030	76.65 43.00	X.	,		
43,60	4030	43,00	¥			
3.78	4030	3,196	X			
2.46	430					
24.20	4 020					
5,79	4 .020	5.787	*			
800	+ 1004 - 1001					
650	4 ,010	,034	*			
						3-5
		<u> </u>				
		*				
				<del>                                     </del>	<u>                                     </u>	
	1		1	L	L	

Measured by:	iB	Audited by:	Prototype Approval:	N/A
Date:	9-10-6	Date: 09/w was	Date:	N/A

Rev	Date	Change	Revised by	Approved
1101			KJ/JLM	
. A		New Issue		



	DESIGN 4	DRAWN BY		EROSPACE LTD URY, ONTARIO, CANADA		
	CHECKED	APPROVED ,	DRAWING NO.		REV. F	
	Melk	#	D3140	SHEET	1 OF 7	
	DATE		TITLE		SCALE	
	06.10.06		DOOR		NTS	
_						

RELEASED 06.11.13

	06.1	0.06	DOOR NTS
	Α	02.04.18	NEW ISSUE
	В	03.01.23	REMOVE -65/-81/-83; ADD -301/-303
	ပ	04.11.08	CHANGE DELASTEK SPEC. TEC-77; ADD PART MARKING; ADD NOTES 11, 12, 13; CHANGE ANGLE -95/-97/-98 TO 106
	D	05.11.23	ADD -103/-104/-105/-106; REMOVE -67
	E	06.06.09	1.75 WAS 1.88, 4.75 WAS 4.13 ON -08/-07, 1.00 WAS 1.20 ON -09/-10
	F	06.10.06	ADD NOTE 14; CORRECT PART TITLE, NOW D3140-09/-92/-104 SHOWN D3140-10/-91/-103 OPPOSITE

QTY -05	QTY -06	QTY -07	QTY -08	QTY -09	QTY -10	PART NUMBER	DESCRIPTION
Х	····	-				D3140-05	DOOR
	X					D3140-06	DOOR
		Х				D3140-07	DOOR
			Х			D3140-08	DOOR
		1		Х		D3140-09	DOUBLER ASSEMBLY
			1		Х	D3140-10	DOUBLER ASSEMBLY
3	3					D3140-57	PAD
1	1					D3140-59	PAD
2	2					D3140-61	PAD
2	2					D3140-63	PAD
		1	1			D3140-69	PAD
		1	1			D3140-71	PAD
		1	1			D3140-73	PAD
		1	1			D3140-75	PAD
		1	1			D3140-77	PAD
		1	1			D3140-79	PAD
				1	1	D3140-85	ANGLE
1	1					D3140-87	DOUBLER
				1	1	D3140-89	DOUBLER
		1				D3140-91	DOUBLER
			1			D3140-92	DOUBLER
3	3					D3140-95	DOUBLER
1						D3140-97	DOUBLER
	1					D3140-98	DOUBLER
		1	1			D3140-99	DOUBLER
		2	2			D3140-101	DOUBLER
		1				D3140-103	DOUBLER
			1			D3140-104	DOUBLER
		1				D3140-105	DOUBLER
			1			D3140-106	DOUBLER
1	11					D3140-241	DOUBLER
1		1				D3140-301	DOUBLER
	1		1			D3140-303	DOUBLER
				5	5	MS20426AD3-4	RIVET

Copyright 2002 by DART AEROSPACE LTD

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.



DESIGN 4	CB		ROSPACE LTD (, ONTARIO, CANADA
CHECKED	APPROVED	DRAWING NO.	REV. F SHEET 2 OF 7
DATE		TITLE	SCALE
06.10.06		DOOR	NTS



COMPOSITE LAYUP & BONDING I.A.W. DELASTEK PROCESS SPEC. TEC-77 MATERIAL STORAGE & HANDLING TO BE I.A.W. DART QSI 006 MAIN LAYUP USES FIBERCOTE E-761/7781 EPOXY FIBERGLASS. FILL WITH EPOCAST 87269 OR MAGNOBOND 77 A & B AND MA560 FOAM/ NB-51/30 FOAM



FINISH: DUPONT HIGHBUILD GREY PRIMER 1144-S

MAKE PARTS IN ACCORDANCE WITH THE FOLLOWING TOOLS/MOLDS:

<u>PART</u>	TOOL
D3140-05	B30-23000-01T
D3140-06	B30-23000-02T
D3140-07	B30-23000-03T
D3140-08	B30-23000-04T
D3140-57	B30-23000-57T
D3140-61	B30-23000-61T
D3140-63	B30-23000-63T
D3140-69	B30-23000-69T
D3140-71	B30-23000-71T
D3140-73	B30-23000-73T
D3140-75	B30-23000-75T
D3140-77	B30-23000-77T
D3140-79	B30-23000-79T
D3140-89	D3140-89T1
D3140-301	D3140-301T1
D3140-303	D3140-303T1



MATERIAL: 2024-T3 (QQ-A-250/4) 0.032 THICK (M2024T3S.032) FINISH: CHEMICAL CONVERSION COAT PER DART OSI 005 4.1



MATERIAL: 2024-T3 (QQ-A-250/4) 0.020 THICK (M2024T3S.020) FINISH: CHEMICAL CONVERSION COAT PER DART QSI 005 4.1



MATERIAL: 5052-H32/H34 (QQ-A-250/8) 0.040 THICK (M5052H32S.040) FINISH: CHEMICAL CONVERSION COAT PER DART QSI 005 4.1



MATERIAL: POLIMEX TR75 1" THICK 4.5 LB KLEGECELL



**ALL DIMENSIONS IN INCHES** 



TOLERANCES ARE PER DART QSI 018 UNLESS OTHERWISE NOTED



MATERIAL: 6061-T6 (QQ-A-250/11) 0.063 THICK (M6061-T6S.063) FINISH: CHEMICAL CONVERSION COAT PER DART QSI 005 4.1



DOUBLER TO SIT ON TOP OF FOAM AT THIS LOCATION



DOUBLER TO BE RECESSED FLUSH INTO FOAM AT THIS LOCATION



RUBBER STAMP WITH DART P/N D3140-05/-06/-07/-08 USING MIL-STD-130



PARTS MUST BE SCUFFED WITH 80 GRIT SANDPAPER PRIOR TO ACID ETCH AND ALODINE PER DART QSI 005 4.1



Copyright © 2002 by DART AEROSPACE LTD

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.









